



Twingo
Kangoo
Clio
Mégane
Scénic
Laguna

Type

S/Section

Type	S/Section
X06 X	88
XCO X	88
XBX X	88
XAX X	88
JAX X	88
XGO X	88

88 **AUTOMATIC DOOR LOCKING WHEN DRIVING**

Other sub-sections concerned:

82 **83**

- Engine: **XXX**
- Gearbox: **XXX**

Reminder concerning the operation of the "Automatic door locking when driving" (RAID) function.

The decoder unit* must be configured correctly using the diagnostic tool for the customer to be able to activate the function with the central locking switch:

- the state "**ET005 RAID authorised by fault finding**" must be ACTIVE
- to change the configuration, use the "**5300 RAID function inhibition**" command (ignition turned off).

To operate this function:

- switch on the ignition,
- keep central locking switch pressed in until the signal is heard,
- the state "**ET016 RAID authorised by central door locking**" must be ACTIVE.

* this function is operated by the UCH or the multi-timer unit, depending on the vehicle.

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.