

Kangoo

Clio

TECHNICAL NOTE 3432A

XB0X - XC0X

FAULT FINDING

SAGEM PETROL INJECTION

COMPUTER TYPE: SAFIR 2
PROGRAM No.: AF
35 TRACK

77 11 297 762

DECEMBER 2000

EDITION ANGLAISE

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

© RENAULT 2000

Contents

	Page
17 PETROL INJECTION	
Introduction	17-1
Fault interpretation	17-3
Conformity check	17-22
Status interpretation	17-28
Parameter interpretation	17-31
Control interpretation	17-34
Help	17-35
Customer complaints	17-37
Fault finding chart	17-38

This document describes the generic fault finding strategy applicable to all SAFIR 2, program no. AF, 35 track computers.


The following are thus required to carry out fault finding on this system:

- the "Fault finding" Technical Note,
- the wiring diagram of the function on the vehicle concerned,
- the tools listed under Special tooling required.

GENERAL APPROACH TO FAULT FINDING:

- Use of one of the fault finding tools to identify the system equipping the vehicle (to read the computer family, SAFIR 2, program no. AF, 35 track computers (command LC046)).
- Finding the "Fault finding" documents corresponding to the system identified.
- Taking note of information contained in the introductory sections.
- Reading the faults stored in the computer memory and using the "Fault interpretation" section of the documents.
Reminder: Each fault is interpreted for a particular type of storage (fault present, fault stored, fault present or stored). The checks defined for handling each fault are therefore only to be performed if the fault shown by the fault finding tool is interpreted in the document for its type of storage. The storage type should be considered when using the fault finding tool following ignition switch-off and switch-on.
If a fault is interpreted when it is stated to be "stored", the conditions for application of the fault finding procedure appear in the "NOTES" box. When these conditions are not satisfied, use the fault finding procedure to check the circuit of the faulty part since the fault is no longer present on the vehicle. Follow the same procedure when a fault is shown as "stored" by the fault finding tool but is only interpreted in the documentation for a "present" fault.
- Perform the conformity check (appearance of possible incorrect operations not yet stated by the system's self diagnosis procedure) and apply the associated fault finding strategy according to results.
- Validation of the repair (disappearance of the phenomenon reported by the customer).
- Use of the fault finding strategy for each "Customer complaint " if the problem persists.

If the information obtained by the fault finding tool requires checking of electrical continuity, connect bornier **MS1048**.



Bornier **MS 1048** is a 35 track base with a printed circuit on which there are 35 copper-coated areas, numbered from 1 to 35.

Using the wiring diagrams, it is easy to identify the cables to be connected for the component(s) to be checked.

IMPORTANT:

- All checks using bornier **MS 1048** can only be carried out with the battery disconnected.
- The bornier is only designed to operate with an ohmmeter. Under no circumstances should 12 volts be applied to the test points.

DF003 PRESENT OR STORED	<u>Air temperature sensor circuit</u> DEF : Unidentified electrical fault
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present following fan activation with the engine running.
-------	--

Check the connection and condition of the air temperature sensor connector. Change the connector if necessary.
Check the condition of the connectors and the insulation and continuity of the connections between: <div>Computer track 2 —————> Air temperature sensor</div> <div>Computer track 15 —————> Air temperature sensor</div> Repair if necessary.
Check the resistance of the sensor. Replace it if necessary.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF004 PRESENT OR STORED	<u>Coolant temperature sensor circuit</u> DEF : Unidentified electrical fault
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present following fan activation with the engine running.
-------	--

Check the connection and condition of the coolant temperature sensor connector. Change the connector if necessary.
Connect the bornier in place of the computer and check the insulation, continuity and absence of interference resistance on the connections between: <div>Computer track 15 —————> Coolant temperature sensor</div> <div>Computer track 6 —————> Coolant temperature sensor</div> Repair if necessary.
Check the sensor resistance at different temperatures (see the Help section). Replace it if necessary.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF006 PRESENT OR STORED	<u>Pinking sensor circuit</u> DEF : Unidentified electrical fault
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present during a road test when the engine is warm and at a high engine speed.
-------	---

Check the connection and condition of the pinking sensor connector. Change the connector if necessary.
Check the condition of the connectors and the insulation, continuity and absence of interference resistance on the connections between: <div><div>Computer track 1</div><div>Computer track 15</div><div>Computer track 16</div></div> <div><div>————→</div><div>————→</div><div>————→</div></div> <div><div>Pinking sensor</div><div>Pinking sensor</div><div>Pinking sensor screening</div></div>
Repair if necessary.
If the fault persists, change the pinking sensor.

AFTER REPAIR	<p>Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.</p>
--------------	--

DF008 PRESENT	Fuel pump relay control circuit CC.1 : Short-circuit to 12 volts
------------------	---

NOTES	None
-------	------

Check the connection and condition of the fuel pump relay connector. Change the connector if necessary.
Disconnect the relay. Check, with the ignition on, for +12 volts on track 1 of the fuel pump relay . Repair if necessary.
Check the fuel pump relay coil. Change the fuel pump relay if necessary.
Check the insulation against +12 volts of the connection between: Computer track 20 —————> Fuel pump relay Repair if necessary.
If the problem has still not been solved, deal with the other faults and then proceed to the conformity check.

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

DF011 PRESENT	<u>Fault warning light circuit</u> CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 volts
------------------	---

NOTES	None
-------	------

Check the condition of the warning light (if it is not lit). Change if necessary.
Check that +12 volts is supplying the fault light (if it is not lit). Rectify the line to the fuse.
Check the insulation and continuity of the connection between: Computer track 19 —————▶ track 6 Instrument panel Repair.

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

DF014 PRESENT	<u>Canister bleed circuit</u> DEF : Unidentified electrical fault
------------------	--



NOTES	None
-------	------

Check the connection and condition of the canister bleed valve connector. Change the connector if necessary.
With the ignition switched on, check for the presence of 12 volts on track A of the canister bleed valve . Repair if necessary.
Check the insulation and continuity of the connection between: Computer track 24 —————> Canister bleed valve Repair if necessary.
Check the resistance of the canister bleed valve. Replace the valve if necessary.

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

DF016 PRESENT OR STORED	<u>Injector circuit</u> .DEF : Fault stored 2.3.CO : Injector 2 or 3 in open circuit or short circuit to earth 2.3.CC : Injector 2 or 3 in short circuit to + 12 volts 1.4.CO : Injector 1 or 4 in open circuit or short circuit to earth 1.4.CC : Injector 1 or 4 in short circuit to +12 volts
--	---

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the engine has been running at idle speed for 5 minutes.
--------------	---

Check the connection and condition of the injector connectors. Change the connector if necessary.
Check the resistance of the value for the two faulty injectors. Replace the injector/s if necessary.
After the ignition has been switched on and during the period specified above , check for 12 volts on track 1 of the faulty injector. Repair if necessary.
Check the insulation and absence of interference resistance on the connections between: <div>Computer track 33  Injectors 1 and 4</div> <div>Computer track 32  Injectors 2 and 3</div> Repair if necessary.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-------------------------	---

DF021 PRESENT	<u>Immobiliser circuit</u> DEF : Stored fault 1.DEF : Coded line fault 2.DEF : Immobiliser code not programmed
--------------------------	---

NOTES	None
--------------	------

1.DEF	NOTES	None
--------------	--------------	------

Connect the bornier in place of the computer and check the insulation, continuity and absence of interference resistance on the wiring on track 30 of the computer. Repair if necessary.		
Refer to the immobiliser fault finding if the fault persists.		

2.DEF	NOTES	None
--------------	--------------	------

Consult the immobiliser fault finding procedure.		
--	--	--

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.	
-------------------------	---	--

DF022 PRESENT	<u>Computer</u> DEF : Unidentified electrical fault
------------------	--

NOTES	None
-------	------

Computer defective or incorrect.
Replace the computer.

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

DF023 PRESENT OR STORED	<u>Oxygen sensor circuit</u> DEF : Unidentified electrical fault
----------------------------------	---

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the engine has been running at 2 500 rpm for 5 minutes.
-------	--

Check the connection and condition of the oxygen sensor connector. Change the connector if necessary.
Check, with the ignition switched on during the period specified above , for: – an earth on track B of the oxygen sensor, – + 12 volts to the fuel pump relay on track A of the oxygen sensor. Repair if necessary.
Check for the presence of earth on track 4 of the injection computer. Repair if necessary.
Check the insulation, continuity and absence of interference resistance on the connection between: Computer track 22 —————> Oxygen sensor Repair if necessary.
Change the oxygen sensor if the fault persists.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF024 PRESENT OR STORED	<u>Vehicle speed sensor circuit</u> DEF : Unidentified electrical fault
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present during a varied road test OR a road test driving uphill at constant speed OR a road test driving downhill with the accelerator in the no load position.
-------	--

Check the connection and condition of the vehicle speed sensor connector. Change the connector if necessary.
Check that the sensor is correctly positioned.
Check on the vehicle speed sensor for: – an earth on track B2 , – +12 volts after ignition on track A . Repair if necessary.
Check the insulation, continuity and absence of interference resistance on the connection between: Computer track 8 —————> Vehicle speed sensor Repair if necessary.
Replace the sensor if the fault persists.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF025 PRESENT OR STORED	<u>Flywheel signal sensor circuit</u> DEF : Fault stored CC.0 : Short circuit to earth from engine target sensor CO.0 : No tooth signal: open circuit or short circuit to earth IN : Target sensor reversed
----------------------------------	---

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present following starter activation for 10 seconds. OR after the engine has been running for 2 minutes.
-------	---

CO.0 - CC.0	NOTES	None.
-------------	-------	-------

Check the flywheel signal sensor resistance. Replace the sensor if necessary.
Check the condition of the flywheel, especially if it has been removed.
Check the condition of the connectors and the insulation, continuity and absence of interference resistance on the connections between: <div>Computer track 13 —————> Flywheel signal sensor</div> <div>Computer track 31 —————> Flywheel signal sensor</div> Repair if necessary.

IN	NOTES	None.
----	-------	-------

Check that the flywheel signal sensor has been correctly connected (the sensor connector must not be reversed). Repair if necessary.
Replace the sensor if the fault persists.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF026 PRESENT OR STORED	Throttle potentiometer circuit DEF : Unidentified electrical fault
----------------------------------	---

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the ignition on is switched on without the accelerator pedal being depressed for the first 10 seconds. OR The fault is declared present when there is a slight variation of the throttle position potentiometer from no load to full load. OR The fault is declared present when there is a full load signal for 10 seconds.
-------	---

Check the connection and condition of the connector on the throttle position potentiometer. Change the connector if necessary.
Check the resistance of the throttle potentiometer. Replace the throttle potentiometer if necessary.
Check the insulation, continuity and absence of interference resistance on the connections between: <div>Computer track 3 —————> Throttle position potentiometer</div> <div>Computer track 5 —————> Throttle position potentiometer</div> <div>Computer track 15 —————> Throttle position potentiometer</div> Repair if necessary.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF036 PRESENT OR STORED	<u>Ignition coil circuit</u> 1.DEF : Fault stored 2.3.CO : Coils 2 and 3 open circuit 2.3.CC : Coils 2 and 3 short circuit 1.4.CO : Coils 1 and 4 open circuit 1.4.CC : Coils 1 and 4 short circuit
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the engine has been running for 10 seconds or at starter speed.
-------	--

Check the 15A fuse on the power supply fuseboard which protects the ignition coil module. Change the fuse if necessary.
Check the connection and condition of the ignition coil connector. Change the connector if necessary.
Check the condition of the connectors and the insulation and continuity of the connections between: <div>Computer track 17 → Ignition coil Computer track 35 → Ignition coil Coil track 3 → Fuse</div> Repair if necessary.
Change the ignition coil if the fault persists.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF041 PRESENT OR STORED	<u>Oxygen sensor heating relay control circuit</u> DEF : Fault stored CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to +12 volts
----------------------------------	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the engine has been running at idle speed for 10 seconds.
-------	--

Check the connection and condition of the connector on the oxygen sensor heating relay. Change the connector if necessary.
Check, with the ignition on, for the presence of +12 volts on track 1 of the oxygen sensor heating relay. Disconnect the relay. Repair if necessary.
Check the heating relay coil. Change the heating relay if necessary.
Check the insulation and continuity of the connection between: Computer track 22 —————> Oxygen sensor heating relay Repair if necessary.
If the problem has still not been solved, deal with the other faults and then proceed to the conformity check.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

INJECTION

Fault finding - Fault Interpretation

DF045 PRESENT OR STORED	<u>Manifold pressure sensor circuit</u> DEF : Unidentified electrical fault 1.DEF: Ignore this fault 2.DEF: Ignore this fault 3.DEF: Ignore this fault
--	--

NOTES	Conditions for applying the fault finding procedure to the fault stored: The fault is declared present after the ignition is switched off and dialogue lost AND the ignition is switched back on and dialogue reestablished AND after the engine has been running at a minimum speed of 608 rpm for 10 seconds.
--------------	---

DEF	NOTES	None
------------	--------------	------

Check for the presence of earth on the fuel pressure regulator.
Check that the pressure sensor is correctly connected both electrically and pneumatically . Check the conformity of the pressure sensor pipe (it must not be pierced or blocked...).
Check the insulation, continuity and absence of interference resistance on the connections between: Computer track 5 —————> Pressure sensor Computer track 15 —————> Pressure sensor Computer track 23 —————> Pressure sensor Repair if necessary.
Replace the sensor if the fault persists.

1.DEF - 2.DEF - 3.DEF	NOTES	None
------------------------------	--------------	------

Ignore these faults.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-------------------------	---

DF140 PRESENT OR STORED	<u>Fan assembly relay output</u> DEF : Fault stored CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to +12 volts
----------------------------------	--

NOTES	Deal with the coolant sensor circuit fault DF004 as a priority. Conditions for applying the fault finding procedure to the fault stored: Apply the fault finding procedure whether the fault is present or stored.
-------	---

Check the connection and condition of the fan assembly relay connector. Change the connector if necessary.
Check for the presence of +12 volts on track 3 of the fan assembly relay. Check, with the ignition on, for the presence of 12 volts on track 1 of the fan assembly relay. Repair if necessary.
Disconnect the relay. Check the coil in the fan assembly relay. Replace the fan assembly relay if necessary.
Check the insulation and continuity of the connections between: <div>Computer track 27 —————> Fan assembly relay Fan assembly relay —————> Fan assembly Fan assembly —————> Earth</div> Repair if necessary.
Disconnect the fan assembly. Connect track 2 of the fan assembly relay to earth. Switch on the ignition. Check for the presence of +12 volts on the fan assembly connector. Warning: this operation may cause the reappearance of the DF140 Fan assembly relay output fault. If +12 volts is not present, change the fan assembly relay.
Change the fan assembly if the fault persists.

AFTER REPAIR	Clear the fault memory. Follow the instructions to confirm repair. Deal with any other possible faults.
-----------------	---

DF143 PRESENT	<u>Idle speed regulation solenoid valve circuit</u> DEF : Unidentified electrical fault
------------------	--

NOTES	None
-------	------

<p>Check the connection and status of the idle speed regulation solenoid valve connector. Change the connector if necessary.</p>																
<p>Check the resistance of the idle speed regulation stepper motor. Change the idle regulation valve if necessary.</p>																
<p>Connect the bornier in place of the computer and check the insulation, continuity and absence of interference resistance on the connections between:</p> <table><tr><td>Computer</td><td>track 11</td><td>————></td><td>Idle speed regulation solenoid valve stepper motor</td></tr><tr><td>Computer</td><td>track 12</td><td>————></td><td>Idle speed regulation solenoid valve stepper motor</td></tr><tr><td>Computer</td><td>track 28</td><td>————></td><td>Idle speed regulation solenoid valve stepper motor</td></tr><tr><td>Computer</td><td>track 29</td><td>————></td><td>Idle speed regulation solenoid valve stepper motor</td></tr></table> <p>Repair if necessary.</p>	Computer	track 11	————>	Idle speed regulation solenoid valve stepper motor	Computer	track 12	————>	Idle speed regulation solenoid valve stepper motor	Computer	track 28	————>	Idle speed regulation solenoid valve stepper motor	Computer	track 29	————>	Idle speed regulation solenoid valve stepper motor
Computer	track 11	————>	Idle speed regulation solenoid valve stepper motor													
Computer	track 12	————>	Idle speed regulation solenoid valve stepper motor													
Computer	track 28	————>	Idle speed regulation solenoid valve stepper motor													
Computer	track 29	————>	Idle speed regulation solenoid valve stepper motor													

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

DF147 PRESENT	Memory circuit DEF : Unidentified electrical fault
------------------	---

NOTES	None
-------	------

<p>This fault only appears when the computer supply has been cut (disconnection of the battery from the computer, ...).</p> <p>Check the correctness of the computer supply voltage:</p> <div><div>Computer track 18</div><div>—————></div><div>Main relay.</div></div> <div><div>Main relay track 3</div><div>—————></div><div>30A fuse</div></div> <div><div>Computer track 26</div><div>—————></div><div>Main relay.</div></div> <div><div>Main relay track 1</div><div>—————></div><div>30A fuse</div></div> <div><div>Computer track 20</div><div>—————></div><div>Petrol pump relay</div></div> <div><div>Petrol pump relay track 1</div><div>—————></div><div>30A fuse</div></div> <p>Repair if necessary.</p>	
<p>Run the engine.</p> <p>Switch off the ignition and wait for the dialogue between the fault finding tool and the computer to be lost.</p> <p>Switch on the ignition.</p> <p>Establish dialogue with the computer.</p> <p>Clear the computer memory.</p> <p>NOTE: stored faults are erased. It would therefore be useful to carry out a road test to check that there are no faults on the injection system.</p>	

AFTER REPAIR	Clear the fault memory. Deal with any other possible faults.
-----------------	---

PETROL INJECTION

Fault finding - Conformity check

NOTES

The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.
Test conditions: Engine stopped, ignition on.

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
1	Battery voltage	ET001 + After ignition PR004 Computer supply voltage	Status CONFIRMED 11.8 < X < 13.2 V	In the event of a problem, consult fault finding procedure PR004
2	Immobiliser (if option)	ET002 Immobiliser	Status NOT CONFIRMED	In the event of a problem, consult fault finding procedure DF021
3	Computer configuration	ET044 Computer configuration with manual gearbox ET082 Automatic gearbox configuration	Status CONFIRMED If the vehicle is fitted with a manual gearbox Status CONFIRMED If the vehicle is fitted with an automatic gearbox	None
4	Throttle position potentiometer	Accelerator pedal released ET003 Throttle position: no load PR017 Measured throttle position ET005 Throttle position: full load Accelerator pedal lightly depressed: ET003 Throttle position: no load ET005 Throttle position: full load	Status CONFIRMED 10 < X < 50 Status NOT CONFIRMED Status NOT CONFIRMED Status NOT CONFIRMED	In the event of a problem, consult fault finding procedure PR017

PETROL INJECTION

Fault finding - Conformity check

17

NOTES

The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.
Test conditions: Engine stopped, ignition on.

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
4	Throttle position potentiometer (continued)	Accelerator pedal pressed ET003 Throttle position: no load PR017 Measured throttle position ET005 Throttle position: full load	Status NOT CONFIRMED $185 < X < 245$ Status CONFIRMED	In the event of a problem, consult fault finding procedure PR017
5	Pressure sensor	PR001 Manifold pressure PR016 Atmospheric pressure	X: atmospheric pressure X: atmospheric pressure	In the event of a problem, consult fault finding procedure DF045
6	Coolant temperature sensor	PR002 Coolant temperature	X = Engine temperature $\pm 5\text{ }^{\circ}\text{C}$	In the event of a problem, consult fault finding procedure DF004
7	Air temperature sensor	PR003 Air temperature	X = Temperature under bonnet $\pm 5\text{ }^{\circ}\text{C}$	In the event of a problem, consult fault finding procedure DF003
8	Canister bleed solenoid valve	AC016 Canister bleed solenoid valve	The activation of the canister bleed valve can be heard	In the event of a problem, consult fault finding procedure DF014

NOTES	<p>The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.</p> <p>Test conditions: Engine stopped, ignition on.</p>
-------	--

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
9	Fault warning light	AC211 Fault warning light	Fault warning light must light up then go out	In the event of a problem, consult fault finding procedure DF011
10	Petrol pump	AC010 Petrol pump relay	Petrol pump should be heard to operate	In the event of a problem, consult fault finding procedure AC010

PETROL INJECTION

Fault finding - Conformity check

NOTES

The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.
Test conditions: Engine warm at idle speed, no electrical consumers.

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
1	Flywheel signal sensor	ET060 Flywheel signal with engine running	Status CONFIRMED	In the event of a problem, consult fault finding procedure DF025
2	Charging circuit	ET001 + After ignition PR004 Computer supply voltage	Status CONFIRMED $13 < X < 14.5 \text{ V}$	In the event of a problem, consult fault finding procedure PR004
3	Throttle potentiometer	ET003 Throttle position: no load	Status CONFIRMED	In the event of a problem, consult fault finding procedure PR017
4	Idle speed regulation	ET039 Idle speed regulation PR006 Engine speed PR022 Idling opening cyclic ratio PR021 Idling opening cyclic ratio adaptive	Status CONFIRMED $690 < X < 790 \text{ rpm}$ $4 \% < X < 14\%$ $-4.3 \% < X < 3.9 \%$	In the event of a problem, consult fault finding procedure ET039
5	Anti-pinking circuit	PR013 Average pinking signal	X: variable and not zero	In the event of a problem, consult fault finding procedure DF006
6	Pressure circuit	PR001 Manifold pressure PR016 Atmospheric pressure	$270 < X < 500 \text{ mb}$ X = atmospheric pressure	In the event of a problem, consult fault finding procedure DF045

NOTES	<p>The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.</p> <p>Test conditions: Engine warm at idle speed, no electrical consumers.</p>
-------	---

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
7	Richness ratio regulation	<div><div>ET037</div>Richness ratio regulation</div> <div><div>PR005</div>Oxygen sensor voltage</div> <div><div>PR035</div>Richness correction value</div>	<div>Status CONFIRMED</div> <div>50 < X < 900 mV</div> <div>0 < X < 255</div>	<div>In the event of a problem, consult fault finding procedure</div> <div>ET037</div>
8	Power assisted steering pressostat	<div><div>ET034</div>Power assisted steering pressostat</div>	<div>Status CONFIRMED</div>	<div>In the event of a problem, consult fault finding procedure</div> <div>ET034</div>
9	Cooling fan assembly	Warm up the engine	<div>X ≥ 99°C</div> <div>The fan should run</div>	<div>In the event of a problem, consult fault finding procedure</div> <div>DF140</div>

PETROL INJECTION

Fault finding - Conformity check

NOTES

The values shown in this conformity check are only given as an indication. It is therefore vital to consult the Technical Note which deals with your vehicle.
Test conditions: Road test.

Order	Function	Configuration/status checked or action	Display and notes	Fault finding
1	Vehicle speed signal	PR018 Vehicle speed	X = speed read on speedometer in km/h	In the event of a problem, consult fault finding procedure DF024
2	Adaptive richness	Programming PR030 Operating adaptive richness PR031 Idle adaptive richness	106 < X < 150 106 < X < 150	In the event of a problem, consult fault finding procedure PR030
3	Pollutant emissions	2 500 rpm after having driven At idle speed, wait for stabilisation	CO < 0.3 % CO ₂ > 13.5 % O ₂ < 0.8 % HC < 100 ppm 0.97 < λ < 1.03 CO < 0.5 % HC < 100 ppm 0.97 < λ < 1.03	In the event of a problem, consult the Technical Note on Antipollution

ET034	<u>Power assisted steering pressure switch</u>
-------	--

NOTES	There must be no faults present or stored.
-------	--

<p>Check the correct operation of the power assisted steering (fluid level, ...).</p> <p>Check for reliable connection of the power assisted steering pressure switch.</p> <p>Check the insulation, continuity and interference resistance of the electrical line:</p> <div><div>Computer track 27</div><div>————></div><div>Power steering pressure switch.</div></div> <div><div>Power assisted steering pressure switch</div><div>————></div><div>Earth</div></div>	
If these points are correct, replace the power assisted steering pressure switch.	

AFTER REPAIR	Restart the conformity check from the beginning.
--------------	--

ET037	<u>Richness regulation</u>
-------	----------------------------

NOTES	There must be no faults present or stored.
-------	--

<p>Check the connection and condition of the upstream oxygen sensor connector. Repair if necessary.</p>
<p>Check for +12 volts on the upstream oxygen sensor. Check the insulation and continuity of the connections between:</p> <div><div>Computer track 22</div><div>Oxygen sensor</div><div>Oxygen sensor</div></div> <div><div>—————></div><div>—————></div></div> <div><div>Oxygen sensor</div><div>Earth</div></div> <p>Repair if necessary.</p>
<p>Check ignition. Check the sealing of the canister bleed valve (a leak can disrupt the richness considerably). Check the exhaust system tightness Check the tightness of the inlet manifold. If the vehicle has only been driven in town, the sensor will be dirty (try driving under load). Check the fuel pressure. If idling is unstable, check the valve clearances and timing. If necessary, replace the oxygen sensor.</p>

AFTER REPAIR	Restart the conformity check from the beginning.
--------------	--

ET039	<u>Idle speed regulation</u>
--------------	------------------------------

NOTES	There must be no faults present or stored.
--------------	--

Check the resistance of the idle speed regulation stepper motor. Change the idle speed regulation valve if necessary.	
Check the insulation and continuity of the connections between: <div><div>Computer track 11</div><div>Computer track 28</div><div>Computer track 12</div><div>Computer track 29</div></div> <div><div>→</div><div>→</div><div>→</div><div>→</div></div> <div><div>Idle speed regulation motor</div><div>Idle speed regulation motor</div><div>Idle speed regulation motor</div><div>Idle speed regulation motor</div></div>	
Repair if necessary and continue fault finding.	

Idle speed variance < minimum stop	NOTES	Idle speed is too slow.
---------------------------------------	--------------	-------------------------

Idle speed regulation is not maintaining the idle speed. – Clean the air supply circuit (throttle body, idle speed regulation stepper motor), since it is probably dirty. – Check the engine oil level (too high --> splashing). – Check for and ensure correct fuel pressure. – Check the engine compression – Check the valve clearances and timing. If all these points are correct, replace the idle speed regulation motor.	
--	--

Idle speed variance > minimum stop	NOTES	Idle speed is too high.
---------------------------------------	--------------	-------------------------

An air leak may be affecting the idle speed regulation strategy. – - Check the connections on the manifold. – - Check the correctness of the pipes on the manifold. – - Check the pneumatically controlled solenoid valves. – - Check the manifold gaskets. – - Check the throttle body gaskets. – - Check the brake servo sealing. – - Check that the restrictions are present in the oil vapour rebreathing circuit. – Check the fuel pressure. If all these points are correct, replace the idle speed regulation motor.	
--	--

AFTER REPAIR	Restart the conformity check from the beginning.
---------------------	--

Fault finding - Parameter interpretation

PR004	<u>Computer supply voltage</u>
-------	--------------------------------

NOTES	There must be no faults present or stored. No consumers
-------	--

Ignition on

If voltage < minimum, the battery is discharged:: Check the charging circuit to determine the cause of this fault.
If voltage > maximum, the battery may be over-charged: Check that the charging voltage is correct with and without consumers.

At idle speed

If voltage < minimum, the charging voltage is too low: Check the charging circuit to determine the cause of this fault.
If voltage > maximum, the charging voltage is too high: The alternator regulator is faulty. Repair this fault and check the electrolyte level in the battery.

AFTER REPAIR	Restart the conformity check from the beginning.
--------------	--

PR017	<u>Measured throttle position</u>
-------	-----------------------------------

NOTES	There must be no faults present or stored. No consumers
-------	--

<div>Check the insulation, continuity and absence of interference resistance on the connections between:</div> <div><div>Computer track 3</div><div>Computer track 5</div><div>Computer track 15</div><div>Computer track 4</div><div>Computer track 35</div><div>Computer track 17</div></div> <div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div></div> <div><div>Throttle position potentiometer</div><div>Throttle position potentiometer</div><div>Throttle position potentiometer</div><div>Earth</div><div>Ignition coil</div><div>Ignition coil</div></div> <div>Repair if necessary.</div>
<div>Check the resistance of the throttle potentiometer.</div> <div>Replace the throttle potentiometer if necessary.</div>
<div>Check the resistance of the coil.</div> <div>If the coil is faulty, replace it before continuing with the fault finding procedure.</div>

AFTER REPAIR	Restart the conformity check from the beginning.
--------------	--

Fault finding - Parameter interpretation

PR030

Operating adaptive richness

NOTES

There must be no faults present or stored.
No consumers

Ensure the canister bleed valve is tight.

Clear the computer memory.

With the engine hot and running at regulated idle speed, observe the operating richness adaptive and the idle richness adaptive.

- If the operating richness adaptive and the idle richness adaptive go to the **MAXI** stop, there is insufficient fuel.
- If the operating richness adaptive and the idle richness adaptive go to the **MINI** stop, there is excess fuel.

Ensure the correctness, cleanliness and proper operation:

- of the filter,
- of the fuel pump,
- of the fuel circuit,
- of the tank.

**AFTER
REPAIR**

Restart the conformity check from the beginning.

AC010	<u>Fuel pump relay</u>
-------	------------------------

NOTES	There must be no faults present or stored.
-------	--

Check that the impact sensor is switched on . Switch on the impact sensor if necessary.
Check the continuity between tracks 1 and 3 of the impact sensor . If there is no continuity, change the impact sensor.
With the starter motor on, check for + 12 volts on track 3 of the impact sensor connector . If +12 volts is not present, correct the line from track 3 of the impact sensor to track L5 of the fuel pump relay.
Check the correctness and presence of earth on the fuel pump .
Check the insulation and continuity of the connection between: Impact sensor track 1 —————> Fuel pump (see wiring diagram) Repair if necessary.
If the fault persists, change the fuel pump.

AFTER REPAIR	Restart the conformity check from the beginning.
--------------	--

Refer to section 12

of the Technical Note which deals with your vehicle to obtain the exact values

Injector resistance		=	14.5 Ω	
Idle regulation stepper motor resistance		A-D = 100 Ω		
		B-C = 100 Ω		
Canister bleed valve resistance		=	35 Ω	
Ignition coil resistance	Primary	=	1-4; 1-3; 2-3; 2-4 = 1.5 Ω	
			3-4 = 0.6 Ω	
	Secondary	=	8 k Ω	
Oxygen sensor heater resistance		=	3 à 15 Ω	
Throttle potentiometer resistance	PL	A-B = 1300 Ω	PF	A-B = 1300 Ω
		A-C = 1360 Ω		A-C = 2350 Ω
		B-C = 2300 Ω		B-C = 1260 Ω
Flywheel signal resistance		=	220 Ω	
Fuel pressure regulator		=	3 bar with the ignition on / 2.5 bar at idle speed	
Value for	CO	=	0.3 % max	
	HC	=	100 ppm max	
	CO ₂	=	14.5 % min	
	Lambda	=	0.97 < λ < 1.03	

Temperature in °C	0	20	40	80	90
Air temperature sensor Resistance in ohms	5000 to 7000	1700 to 3300	500 to 1550	-	-
Coolant temperature sensor Resistance in ohms	6700 to 8000	2600 to 3000	1100 to 1300	270 to 300	200 to 215

NOTES	Only consult the customer complaints after a complete check using the fault finding tool.
-------	---

NO COMMUNICATION WITH THE FAULT FINDING TOOL	CHART 1
STARTING PROBLEMS	CHART 2
IDLE SPEED FAULTS	CHART 3
PROBLEMS WHEN DRIVING	CHART 4

CHART 1	NO COMMUNICATION WITH THE FAULT FINDING TOOL
---------	--

NOTES	Only consult the customer complaints after a complete check using the fault finding tool.
-------	---

Try the fault finding tool on another vehicle.
Check: – the injection, engine and passenger compartment fuses. Repair if necessary.
Check for + 12 volts on track 16 and for earth on track 5 of the diagnostic socket. Repair if necessary.
Check, with the ignition on, for +12 volts on track: – 1 of the main relay, – 3 of the main relay, – 1 of the fuel pump relay.
Connect the bornier in place of the computer and check the insulation and continuity of the connections between: <div>Computer track 4 → Earth Computer track 16 → Earth Computer track 34 → Earth Computer track 9 → Track 7 Diagnostic socket Computer track 10 → Track 15 Diagnostic socket Computer track 18 → Track 5 Main relay Computer track 26 → Track 2 Main relay Computer track 20 → Track 2 Fuel pump relay</div> Repair if necessary.
With the ignition on, check for +12 volts on track 5 of the main relay: – If +12 volts is present on track 5 of the main relay: replace the fuel pump relay. – If +12 volts is not present on track 5 of the main relay: replace the main relay.

AFTER REPAIR	Test using the fault finding tool.
--------------	------------------------------------

CHART 2	STARTING PROBLEMS
---------	-------------------

NOTES	This Customer Complaint should only be investigated after a complete check has been run using the fault finding tool.
-------	---

Check for the presence of earth on the fuel pressure regulator. Check that there is fuel present (fuel gauge faulty). Check that the fuel is of the proper type. Check that no hoses are pinched (especially after a removal operation). Check the condition of the tank.	
Check the fuel pump supply. Check that the impact sensor is operating correctly.	
Check the idle speed regulation valve. Tap gently to release the valve.	
Disconnect the pipe connecting the canister bleed solenoid valve to the inlet manifold. Plug the pipe to prevent an air leak. If there is no further fault, the canister bleed is faulty.	
Check the condition of the plugs and coils. Check that these elements are correct for the vehicle.	
Check that the exhaust system is not blocked nor the catalytic converter clogged.	
Check the engine compression.	
Check the condition of the flywheel.	

AFTER REPAIR	Clear the computer memory using the fault finding tool and carry out a road test.
--------------	---

CHART 3	IDLE SPEED FAULTS
---------	-------------------

NOTES	This Customer Complaint should only be investigated after a complete check has been run using the fault finding tool.
-------	---

Check for the presence of earth on the fuel pressure regulator. Check that there is fuel present (fuel gauge faulty). Check that the fuel is of the proper type. Check that no hoses are pinched (especially after a removal operation). Check the condition of the tank.
Check the idle speed regulation valve. Tap gently to release the valve.
Disconnect the pipe connecting the canister bleed solenoid valve to the inlet manifold. Plug the pipe to prevent an air leak. If there is no further fault, the canister bleed is faulty.

Check the condition of the plugs and coils. Check that these elements are correct for the vehicle.

Check that the exhaust system is not blocked nor the catalytic converter clogged.

Check on the dipstick that the oil level is not too high
Check the condition of the inlet manifold gaskets.
Check that the throttle valve unit is not clogged.
Check that the brake servo is not leaking (noise).
Check the condition of the flywheel.

AFTER REPAIR	Clear the computer memory using the fault finding tool and carry out a road test.
--------------	---

CHART 4	PROBLEMS WHEN DRIVING
---------	-----------------------

NOTES	This Customer Complaint should only be investigated after a complete check has been run using the fault finding tool.
-------	---

<div>Check for the presence of earth on the fuel pressure regulator.</div> <div>Check that the air filter is not distorted.</div> <div>Check that there is fuel present (fuel gauge faulty).</div> <div>Check that the fuel is of the proper type.</div> <div>Check that no hoses are pinched (especially after a removal operation).</div> <div>Check the condition of the tank.</div>	
<div>Disconnect the pipe connecting the canister-bleed solenoid valve to the inlet manifold.</div> <div>Plug the pipe to prevent an air leak.</div> <div>If there is no further fault, the canister bleed is faulty.</div>	
<div>Check the condition of the plugs and coils.</div> <div>Check that these elements are correct for the vehicle.</div>	
<div>Check that the exhaust system is not blocked nor the catalytic converter clogged.</div>	
<div>Check on the dipstick that the oil level is not too high</div>	
<div>Check the condition of the inlet manifold gaskets.</div>	
<div>Check that the throttle valve unit is not clogged.</div>	
<div>Check that the injectors do not drip after removal.</div>	
<div>Check that the brake servo is not leaking (noise).</div>	
<div>Check that the calipers, drums and bearings are not seized.</div> <div>Check that the tyres are not under-inflated.</div>	
<div>Ensure that the cooling function is satisfactory.</div>	

AFTER REPAIR	Clear the computer memory using the fault finding tool and carry out a road test.
--------------	---