



# **0** General information

## **07** VALUES AND SETTINGS

## Contents

	Page
<b>07</b> <b>VALUES AND SETTINGS</b>	
Tyres and wheels	07-1
Underbody height	07-2
Front axle geometry checking values	07-3
Rear axle geometry checking values	07-5

---

Vehicle (engine)	Rim	Tyres	Tyre pressure (in bar) (1) when cold	
			Front	Rear
D7F/D4F	5.5 J 14 6.0 J 15 (2)	175/65 R 14 T 185/55 R 15 H (2)	2.0	2.0
K4J without automatic gearbox	5.5 J 14 6.0 J 15 (2)	175/65 R 14 T 185/55 R 15 H (2)	2.3	2.1
K4J with automatic gearbox	5.5 J 14 6.0 J 15 (2)	175/65 R 14 T 185/55 R 15 H (2)	2.4	2.2
K4M without automatic gearbox	6.0 J 15	185/55 R 15 H	2.3	2.1
K4M with automatic gearbox	6.0 J 15	185/55 R 15 H	2.4	2.2
K9K/F9Q	5.5 J 14 6.0 J 15 (2)	175/65 R 14 T 185/55 R 15 H (2)	2.3	2.1

(1) With full load and on motorways.

(2) Fitting specification.



Wheel nut tightening torque: **9 daNm**


Rim run-out: **1.2 mm**

# VALUES AND SETTINGS

## Underbody height

07

### MEASUREMENT POINTS



13491R6

Measurements H1 and H4 are taken on the wheel shaft.

Measurement H2 is taken between the lower surface of the sub-frame on the right of the wheel shaft and the ground.






Measurement H5 is taken at the shaft of the rubber bush.

# VALUES AND SETTINGS

## Front axle angle checking values

07

14-inch tyres






ANGLES	VALUES	POSITION OF FRONT AXLE (mm)	ADJUSTMENT
<p><b>CASTOR</b></p>  <p style="text-align: right; font-size: small;">93012-1S</p>	<p> <math>1^{\circ}41'</math>  <math>1^{\circ}56'</math>  <math>2^{\circ}11'</math>  <math>2^{\circ}26'</math>  <math>2^{\circ}41'</math> </p> <p style="text-align: center;">} <math>\pm 30'</math></p> <p style="text-align: center;">Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H5 - H2 = 125</math>  <math>H5 - H2 = 115</math>  <math>H5 - H2 = 105</math>  <math>H5 - H2 = 95</math>  <math>H5 - H2 = 85</math> </p>	<p>Not adjustable</p>
<p><b>CAMBER</b></p>  <p style="text-align: right; font-size: small;">93013-1S</p>	<p> <math>-0^{\circ}22'</math>  <math>-0^{\circ}25'</math>  <math>-0^{\circ}28'</math>  <math>-0^{\circ}30'</math>  <math>-0^{\circ}33'</math> </p> <p style="text-align: center;">} <math>\pm 1^{\circ}</math></p> <p style="text-align: center;">Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H1 - H2 = 87</math>  <math>H1 - H2 = 96</math>  <math>H1 - H2 = 105</math>  <math>H1 - H2 = 113</math>  <math>H1 - H2 = 122</math> </p>	<p>Not adjustable</p>
<p><b>PIVOT</b></p>  <p style="text-align: right; font-size: small;">93014-1S</p>	<p> <math>10^{\circ}42'</math>  <math>10^{\circ}53'</math>  <math>11^{\circ}05'</math>  <math>11^{\circ}18'</math>  <math>11^{\circ}30'</math> </p> <p style="text-align: center;">} <math>\pm 30'</math></p> <p style="text-align: center;">Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H1 - H2 = 87</math>  <math>H1 - H2 = 96</math>  <math>H1 - H2 = 105</math>  <math>H1 - H2 = 113</math>  <math>H1 - H2 = 122</math> </p>	<p>Not adjustable</p>
<p><b>PARALLELISM</b></p>  <p style="text-align: right; font-size: small;">93011-1S</p>	<p>(For two wheels)</p> <p style="text-align: center;">Toe-out</p> <p style="text-align: center;"><math>0^{\circ} 10' \pm 10'</math></p> <p style="text-align: center;"><math>1 \text{ mm} \pm 1 \text{ mm}</math></p>	<p>Unladen</p>	<p>Adjustable by rotating the track rod sleeves</p>
<p><b>POSITION FOR TIGHTENING RUBBER BUSHES</b></p>  <p style="text-align: right; font-size: small;">81603S1</p>	<p>-</p>	<p>Unladen</p>	<p>-</p>

# VALUES AND SETTINGS

## Front axle angle checking values

07




15-inch tyres

ANGLES	VALUES	POSITION OF FRONT AXLE (mm)	ADJUSTMENT
<p><b>CASTOR</b></p>  <p style="text-align: right; font-size: small;">93012-1S</p>	<p> <math>1^{\circ}42'</math>  <math>1^{\circ}59'</math>  <math>2^{\circ}15'</math>  <math>2^{\circ}32'</math>  <math>2^{\circ}48'</math> </p> <p style="text-align: center;">} <math>\pm 30'</math></p> <p>Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H5 - H2 = 124</math>  <math>H5 - H2 = 114</math>  <math>H5 - H2 = 103</math>  <math>H5 - H2 = 93</math>  <math>H5 - H2 = 83</math> </p>	<p>Not adjustable</p>
<p><b>CAMBER</b></p>  <p style="text-align: right; font-size: small;">93013-1S</p>	<p> <math>-0^{\circ}25'</math>  <math>-0^{\circ}27'</math>  <math>-0^{\circ}28'</math>  <math>-0^{\circ}30'</math>  <math>-0^{\circ}31'</math> </p> <p style="text-align: center;">} <math>\pm 1^{\circ}</math></p> <p>Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H1 - H2 = 92</math>  <math>H1 - H2 = 101</math>  <math>H1 - H2 = 110</math>  <math>H1 - H2 = 119</math>  <math>H1 - H2 = 128</math> </p>	<p>Not adjustable</p>
<p><b>PIVOT</b></p>  <p style="text-align: right; font-size: small;">93014-1S</p>	<p> <math>10^{\circ}54'</math>  <math>11^{\circ}04'</math>  <math>11^{\circ}15'</math>  <math>11^{\circ}25'</math>  <math>11^{\circ}36'</math> </p> <p style="text-align: center;">} <math>\pm 30'</math></p> <p>Max. right/left difference = <math>1^{\circ}</math></p>	<p> <math>H1 - H2 = 92</math>  <math>H1 - H2 = 101</math>  <math>H1 - H2 = 110</math>  <math>H1 - H2 = 119</math>  <math>H1 - H2 = 128</math> </p>	<p>Not adjustable</p>
<p><b>PARALLELISM</b></p>  <p style="text-align: right; font-size: small;">93011-1</p>	<p>(For two wheels)</p> <p style="text-align: center;">Toe-out</p> <p style="text-align: center;"><math>0^{\circ}10' \pm 10'</math></p> <p style="text-align: center;"><math>1 \text{ mm} \pm 1 \text{ mm}</math></p>	<p>Unladen</p>	<p>Adjustable by rotating the track rod sleeves</p>
<p><b>POSITION FOR TIGHTENING RUBBER BUSHES</b></p>  <p style="text-align: right; font-size: small;">81603S1</p>	<p>-</p>	<p>Unladen</p>	<p>-</p>

# VALUES AND SETTINGS

## Rear axle angles checking values

07

ANGLES	VALUES	POSITION OF REAR AXLE (mm)	ADJUSTMENT
<p><b>CAMBER</b></p> 	<p><math>-0^{\circ}46' \pm 20'</math></p>	<p>Unladen</p>	<p>Not adjustable</p>
<p><b>PARALLELISM</b></p> 	<p>(For two wheels)</p> <p>Toe-in</p> <p><math>-0^{\circ}40' \pm 30'</math></p> <p><math>-7 \text{ mm} \pm 5 \text{ mm}</math></p>	<p>Unladen</p>	<p>Not adjustable</p>
<p><b>POSITION FOR TIGHTENING RUBBER BUSHES</b></p> 	<p>-</p>	<p>Unladen</p>	<p>-</p>